


# HUANNANZHI H97

进入BIOS开机连续按DEL键/快捷启动按F11键/保存按F10键

## 关闭CPU核心步骤



Aptio Setup Utility - Copyright (C) 2020 American Megat

Advanced

Max CPU Speed	3300 MHz
Min CPU Speed	800 MHz
CPU Speed	3500 MHz
Processor Cores	4
Intel HT Technology	Not Supported
Intel VT-x Technology	Supported
Intel SMX Technology	Supported
64-bit	Supported
EIST Technology	Supported
CPU C3 state	
CPU C6 state	
CPU C7 state	

L1 Data Cache  
L1 Code Cache  
L2 Cache  
L3 Cache  
L4 Cache

Active Processor Cores  
Overclocking lock  
Limit CPUID Maximum  
Execute Disable Bit  
Intel Virtualization Technology  
Hardware Prefetcher

Active Processor Cores

All

1

2

3

第三步

6 MB  
Not Present

[All]

[Disabled]

[Disabled]

[Enabled]


[Enabled]

[Enabled]

第二步



# S1.S3睡眠设置步骤



### ACPI Settings

Enable ACPI Auto Configuration	[Disabled]
Enable Hibernation	[Enabled]
ACPI Sleep State	[S1 (CPU Stop Clock)]
Lock Legacy Resources	[Disabled]
S3 Video Repost	[Disabled]

Select the state the system will enter when the S button is pressed.

第二步


ACPI Sleep State

- Suspend Disabled
- S1 (CPU Stop Clock)
- S3 (Suspend to RAM)
- Both S1 and S3 available for OS to choose from

第三步

+/-: Change  
F1: General  
F2: Previous  
F3: Optimize  
F4: Save & Exit  
ESC: Exit

# AC来电启动





PowerManagement Configuration

Wake up by USB Device	[Enabled]
Restore AC Power Loss	[Power Off]
Power On By PS/2 Keyboard	[Disabled]
Power On By PS/2 Mouse	[Disabled]
RTC Power On Function	[Disabled]

开

关

— Restore AC Power Loss —  
Power On  
Power Off  
Last State

将电脑恢复到断电或中断发生之前的状态

Restor

+/: Sel

↓: Sel

Enter: :

+/-: Cha

F1: Gene


F2: Prev

F3: Opti

F4: Save

ESC: Exi

# 定时开机



PowerManagement Configuration

Wake up by USB Device	[Enabled]
Restore AC Power Loss	[Power Off]
Power On By PS/2 Keyboard	[Disabled]
Power On By PS/2 Mouse	[Disabled]
RTC Power On Function	[Disabled]

RTC Power On Function

Disabled  
Enabled  
Dynamic Time


第二步

Enable  
on ala  
system  
hr::mi

+/: Sele  
↓: Sele  
nter: S  
+/-: Cha  
F1: Gene  
F2: Prev  
F3: Opti  
F4: Save  
ESC: Exit



# 风扇温控



# SMART Fan Control

Cpu Smart Fan Control

[Thermal Cruise Model]

CPU Fan Target Temperature

50

CPU Fan Tolerance of Target

5

CPU Fan Starup PWM Output

255

CPU Fan Stop PWM Output

128

CPU Fan StopTime

60

## Pc Health Status

CPU temp

: +52 °C

CPUFan Speed

: N/A

第二步

Cpu Sm

++: Se

↑↓: Se

Enter:

+/-: C

F1: Ge


F2: Pr

F3: Op


F4: Se

ESC: E


# 网卡启动







# UEFI开启步骤



## Compatibility Support Module Configuration

CSM Support [Enabled]

CSM16 Module Version 07.76

GateA20 Active [Upon Request]

Option ROM Messages [Force BIOS]

Boot option filter [UEFI and Legacy]

Option ROM execution

PXE BootROM

Storage

Video

Other PCI devices

— Boot option filter —

UEFI and Legacy

Legacy only

UEFI only

[UEFI]

This opt  
Legacy/L


→←: Select  
↑↓: Select  
Enter: Se  
+/-: Chan  
F1: Gener  
F2: Previo  
F3: Optim  
F4: Save &  
ESC: Exit

第二步


第三步



# 核显开关



# 内存频率



### Memory Information

Memory RC Version 1.8.0.3  
Memory Frequency 1600 Mhz  
Total Memory 32768 MB (DDR3)  
Memory Voltage 1.50v

DIMM#0

DIMM#1

DIMM#2

DIMM#3

CAS Latency (CL)

Minimum delay time

CAS to RAS (tRCDmin)

Row Precharge (tRPmin)

Active to Precharge (tRAS)

XMP Profile 1

XMP Profile 2

DIMM profile

Memory Frequency Limiter

ECC Support

Max TOLUD

Enh Interleave Support

RI Support

DLL Weak Lock Support

### Memory Frequency Limiter

Auto

1067

1333

1600

1867

2133

2400

2667

2933

3200

第三步

第二步

[Auto]

[Enabled]

[Dynamic]

[Enabled]

[Enabled]

[Enabled]


F3:

F4:

ESC:



## 硬盘热拔插功能



Serial ATA Port 0  
Software Preserve  
Port 0  
Hot Plug  
External SATA  
SATA Device Type  
Spin Up Device

Serial ATA Port 1  
Software Preserve  
Port 1  
Hot Plug  
External SATA  
SATA Device Type  
Spin Up Device

Serial ATA Port 2  
Software Preserve  
Port 2  
Hot Plug

第二步

Empty  
Unknown  
[Enabled]


Hot Plug  
Disabled  
Enabled

E  
Unknown  
[Enabled]  
[Disabled]  
[Disabled]  
[Hard Disk Drive]  
[Disabled]  
Empty  
Unknown  
[Enabled]  
[Disabled]

第三步



## 主板开启VT功能步骤





第三步

Intel Virtualization Technology  
Disabled  
Enabled

第二步

Hyper-threading	[Enabled]
Active Processor Cores	[All]
Overclocking lock	[Disabled]
Limit CPUID Maximum	[Disabled]
Execute Disable Bit	[Enabled]
Intel Virtualization Technology	[Enabled]
Hardware Prefetcher	[Enabled]

Version 2.18.1263. Copyright (C) 2020 Ame