


huananzhi a78

进入BIOS开机连续按DEL键/快捷启动按F11键/保存按F10键

取消开机“F1”选项



LED190W

CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrend
Advanced BIOS Features

Advanced BIOS Features

► CPU Configuration	[Press Enter]
Quick Boot	[Enabled]
Full Screen Logo Show	[Enabled]
AddOn ROM Display Mode	[Force BIOS]
Bootup Num-Lock	[ON]
Wait For 'F1' If Error	
Hit 'DEL' Message Display	
Interrupt 19 Capture	

Options

Disabled
Enabled

Help It

Wait for F1
key to be
pressed if
error occurs.

第二步

第三步

F1 Help
Esc Exit

↑↓ Select Item
↔ Select Menu

-/Space Change Values
Enter Select ► Sub Menu

F9 Setup Default
F10 Save and Exit

HUYINIUDA®

查看CPU温度



LED190W

CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrend
PC Health Status

PC Health Status

Help I

CPU Temperature :28°C/82°F

CPU FAN Speed :1506 RPM

Vcore :1.352 V

AVCC :3.328 V

3VCC :3.312 V

+5V :4.959 V

VDIMM :1.520 V

VT1 :1.232 V

USB :3.376 V

F1 Help
Esc Exit


↑↓ Select Item
↔ Select Menu

-/Space Change Values
Enter Select ▶ Sub Menu

F9 Setup De.
F10 Save and

HUYINIUDA®

查看硬盘接口



LED190W

CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
Standard BIOS Features

System Overview

▶ Primary IDE Master	[Not Detected]
▶ Primary IDE Slave	[Not Detected]
▶ SATA 1	[Not Detected]
▶ SATA 2	[Not Detected]
▶ SATA 3	[Not Detected]
▶ SATA 4	[Not Detected]

▶ System Information	[Press Enter]
----------------------	---------------

System Time	[19:37:57]
System Date	[Thu 05/14/2020]
Language	[English]

Help Item

While entering setup, BIOS auto detects the presence of IDE devices. This displays the status of auto detection of IDE devices.

F1 Help
Esc Exit


↑↓ Select Item
↔ Select Menu

-/Space Change Values
Enter Select ▶ Sub Menu

F9 Setup Defaults
F10 Save and Exit

HUYINIUDA®

关闭95W 功耗限制



LED190W

CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
OverClock Settings

OverClock Settings

- ▶ Memory Configuration [Press Enter]
- ▶ DRAM Timing Configuration [Press Enter]
- ▶ AMD K10 FID/VID Configurati [Press Enter]

Processor Frequency (FID) [Auto]
Processor Voltage (VID) [Auto]
CPU-NB HT Link Speed [Auto]
Cool 'n' Quiet [Disabled]
Memory 1T/2T Mode [2T Model]
CPU Power Limit Control [Disabled]

Help Item

Set Enabled,
System will turn off
when cpu power is
over 95W.

第二步

F1 Help
Esc Exit

↑↓ Select Item
↔ Select Menu

-/Space Change Values
Enter Select ▶ Sub Menu

F9 Setup Defaults
F10 Save and Exit

HUYINIUDA®